



# Magic Bullet NutriBullet Pro Rubber Gasket Replacement

Use this guide to replace a damaged rubber gasket on a Magic Bullet NutriBullet Pro for a tight seal that prevents leaks. If the seal is cracked or ripped it will continue to leak.

Written By: Andrew Pana



## INTRODUCTION

This guide will demonstrate how to replace a damaged rubber gasket on the blender blade lid of your cup. The rubber gasket is responsible for sealing the cup from leaking. Other possible problems can be found in our [Troubleshooting Guide](#).



### TOOLS:

- [Tweezers](#) (1)
-



## Step 1 — Rubber Gasket



- Unscrew the blending blade lid from the cup.

## Step 2



- Use tweezers to peel back the rubber gasket that surrounds the inner ring of the lid.

To reassemble your device, follow these instructions in reverse order.